

Selleys Oven Plus Heavy Duty Gel

Description

Oven Plus Heavy Duty Gel is a no fumes heavy duty oven cleaner which is suitable for cleaning oven, cookware and bakeware surfaces.

Product Information

Packaging	Size
Plastic Bottle	400g

Uses

Suitable for cleaning baked-on grease and grime from most oven surfaces and racks as well as heavily soiled cookware and bakeware surfaces.

Features

- Heavy duty gel
- Fast power clean
- No scrubbing required
- No fumes
- No scrubbing required

Technical Details

Property	Typical Result
Colour	Dark blue
Density	~ 1.06
pH	13.5 ± 0.5
Indicative data only, not intended for preparation of specifications	

Directions for Use:

Do not swallow. Read safety directions before using.

- Check your oven instruction manual before using this caustic-based product.
- Not for self or continuous cleaning ovens.
- Ensure room is well ventilated
- Shake well before use
- Wear protective gloves and eye protection.
- Preheat oven to no more than 90°C. Do not overheat as surfaces may be affected. Switch off oven, open door, and allow to stand for 10 minutes before applying product to warm oven surfaces.
- Can be applied by squeezing and spreading with the brush-head or by first squeezing onto a dry sponge and then applying. Apply thin gel layer as directed below. Let stand for 30 minutes, before wiping with a damp cloth e.g. Selleys Super Cloth.

Use a non-scratch scourer for stubborn sections. Then immediately rinse surfaces thoroughly.

Oven Surfaces: Remove racks. Apply onto back wall, then side-walls, and the floor. Then apply to roof by squeezing onto a dry sponge and applying. Finish with door. Place folded paper towels between bottom of door and oven floor. Close door to prevent seepage.

Oven Racks: Lay newspaper on draining board. Squeeze gel onto newspaper and dab bristles in gel. Hold up racks vertically on draining board and apply by running bristles along bars. Place racks back in oven.

Cookware/Bakeware: Wipe surfaces dry immediately after rinsing. After cleaning carbon steel or cast iron, oil surfaces to help prevent flash rusting.

Note:

- The brush-head provided is for spreading gel – not meant for scouring.
- **Do not use on:** pilot lights, electrical connections, switches, heating elements, thermostats, fans, rubber seals, exterior oven surfaces, benchtops aluminium, copper, linoleum, painted surfaces, plastic, glass, galvanised steel or damaged and scratched non-stick cookware/bakeware.
- Product must be applied to warm surfaces
- Rinse cookware & bakeware surfaces thoroughly after cleaning to remove any residue.

Storage

- Store in a cool, dry, well-ventilated place and out of direct sunlight.
- Store away from foodstuffs.

Safety Directions

Do not swallow. Keep out of reach of children

- Corrosive. May produce severe burns
- Avoid contact with skin and eyes
- Wear protective gloves and eye protection.
- Beware of hot surfaces

Warnings, First Aid and Shipping Information

This information can be located on the product SDS found through our website – www.selleys.com