

No More Cracks Wood Filler Interior

Description

Selleys No More Cracks Wood Filler is ready to use and gives a superior, durable finish on interior timber. It is stainable, paintable and has excellent adhesion and can be nailed or planed.

Tips

When tinting or staining, final colour is not achieved until varnish is applied.

Do not use below 5°C.

Where movement occurs use Selleys No More Gaps.

Product Information

Packaging	Size
Tub	270 g

Clean Up

Clean tools and hands with water before filler dries.

Uses

For use on all interior timber.

Storage

Close lid tightly after use and store in a cool dry place.

Features

- Durable
- Easy to sand
- Water clean up

Warnings, First Aid and Shipping Information

This information can be located on the product SDS found through our website – www.selleys.com.au

Technical Details

Property	Typical Result
Appearance	Pine coloured paste
Drying time at 25 °C	1 mm: 1-2 hours 2 mm: 2-3 hours
Indicative data only, not intended for preparation of specifications	

Directions for Use

- Ensure that the surface to be filled is clean and dry with no loose or powder material.
- Use a filling blade or scraper to firmly press the filler in and scrape off excess to minimise sanding.
- Allow to dry for 2-3 hours, depending on humidity, then sand with fine sand paper.
- For a perfect finish apply another thin coat of filler, allow to dry before sanding lightly with very fine sand paper.
- For best results apply an undercoat before your top coat.